

SECURA
SECURA
8-CUP FRENCH PRESS
COFFEE MAKER

Model:SFP-34DS 34-Ounce/1000-ML Stainless Steel 18/10

Model:SFP-34G 34-Ounce with removable Glass Jar

SECURA

Manufactured by Secura Inc.
Brookfield, Wisconsin, USA

Tel: 888-792-2360
CustomerCare@thesecura.com

www.thesecura.com

For warranty claims, please visit our website www.thesecura.com
to submit a warranty claim and provide proof of purchase



Copyright © 2014 – Secura Inc. - All rights are reserved.

The material in this publication is protected under International and Federal Copyright Laws and Treaties, and as such, any unauthorized reprint or use of this material is strictly prohibited.

No part of this book may be reproduced or transmitted in any form without the written permission of the author, except for the inclusion of brief quotations in a review.

Reproduction or translation of any part of this work without the permission of the copyright holder is against the law.

Cleaning & Care Instructions

- Wash in warm soapy water as soon as possible after use.
- Dry thoroughly after cleaning.

Stainless Steel Care Instructions-Prolonged with common corrosive substances such as detergents can damage stainless steel. To extend the life of our stainless steel:

- Never leave dirty stainless steel to soak and always dry stainless steel immediately after washing with a clean, dry cloth.
- Dishwasher safe; do not leave stainless steel overnight to cool down in the dishwasher, or to drip dry. Residues can settle and begin corroding the stainless steel.
- Do not use “rinse and hold” dishwasher cycles with stainless steel.
- Wash stainless steel and silver plated stainless steel separately to avoid damaging the silver plate.

Operation

1. Pull plunger from pot.
2. Add 1 rounded tablespoon of Coarse ground coffee per cup. Fine grinds will clog the filters.
3. Pour hot (not boiling) water into pot. ALWAYS leave a minimum of 25mm space at the top of the pot.
4. Replace the plunger and turn the spout opening away from the spout (if applicable)
5. Allow to brew for at least four minutes. DO NOT plunge.
6. When the coffee has brewed use the weight of your hand to gently push the plunger down.
7. If the filters become clogged, remove the plunger, stir the coffee and plunge again.
8. Align the spout opening to the spout and pour the coffee.

Safety Tips

- Place Cafetiere on flat, non-slip surface. Not for stove top use.
- Do not use a pot that is scratched, cracked or damaged in any way.
- Excessive force when plunging can result in scalding hot liquid being ejected from top of pot.
- Take care when handling hot liquids.

